

Landmark Electronics, Inc. Equipment Repair List

PN	Description
01-524795-1	Receiver-Transmitter
01-524860-1	Receiver-Transmitter
064-1019-00	Receiver-Transmitter
064-1019-04	VHF Receiver-Transmitter
064-1023-00	VHF Receiver-Transmitter
066-1029-03	DME
066-1053-02	Transponder
066-1055-71	Intercom
066-1062-00	Transponder
066-1063-00	Converter
066-1068-01	DME
066-4009-00	Converter
069-1020-00	VHF Receiver-Transmitter
069-1024-05	VHF Receiver-Transmitter
069-1025-25	VHF Receiver-Transmitter
071-1041-01	Power Supply
097967-0200	VHF COMM
1/N-80-774	Indicator
1/N-80-778	Indicator
1/N-80-91	Indicator
1003600000	Receiver-Transmitter
10036200001	Receiver-Transmitter
1003680011	Receiver-Transmitter
1003680038	Receiver-Transmitter
12377	PRT661 ANT
150620	TRANSPONDER
154000	TRANSPONDER
1540620	TRANSPONDER
2031111-0502	Subassembly
204-91799	UHF Receiver-Transmitter
2073404-0705	Power Supply
374D-1	Tacan
377J-1	Control, Set
377J-2	Control, Set
400-0052-177	Receiver-Transmitter
400-0140-077	UHF Receiver-Transmitter
400-0140-177	Receiver-Transmitter
400-0141-010	Control, Set
400-0141-100	Control, Set
400-0141-118	Control, Set
4000695-601	Nav Receiver
4000937-6202	Receiver
4000939-6601	Control, Set
4023400-0502	Transponder
4023400-0503	Transponder
4023400-0504	Transponder
4023402-502	Subassembly
4023402-503	Subassembly
4023411-0501	Subassembly
4023412-0502	Subassembly
4023412-0504	Subassembly
4023414-0502	Subassembly
4023414-0504	Subassembly
4023415-0502	Subassembly
4028683-0502	Subassembly
4028684-502	Subassembly
4030070-502	Subassembly

PN	Description
40323400-0501	Transponder
4036360-0501	TRANSPONDER
4036360-0502	Transponder
4036360-0503	TRANSPONDER
4036360-0504	
4036360-0505	TRANSPONDER
4036360-0506	TRANSPONDER
4036360-0507	Transponder
4036360-0508	Transponder
4036360-0509	Transponder
4036360-0510	Transponder
4036360-0511	TRANSPONDER
4036360-0512	TRANSPONDER
4036360-0513	TRANSPONDER
4036360-0514	TRANSPONDER
4036360-0515	TRANSPONDER
4036360-0516	TRANSPONDER
4036360-0517	TRANSPONDER
4036360-0518	TRANSPONDER
4036360-0519	TRANSPONDER
4036360-0520	Transponder
4K95000-191A	CONTROL
4K95000-193A	TRANSCEIVER
5024030095	Receiver-Transmitter
5024050096	Receiver-Transmitter
5024060091	Receiver-Transmitter
5024080092	Receiver-Transmitter
5024100093	Receiver-Transmitter
5024110099	Receiver-Transmitter
5024120094	Receiver-Transmitter
5024601050	Receiver-Transmitter
5024601092	Receiver-Transmitter
51H1298-1	Tacan
51H1298-2	Tacan
51H1298-3	Tacan
51H1298-4	Tacan
522-0801-005	Mounting Base
522-0952-005	UHF Receiver-Transmitter
522-1230-000	HF Receiver-Transmitter
522-1230-021	HF Receiver-Transmitter
522-1230-022	HF Receiver-Transmitter
522-1230-023	HF Receiver-Transmitter
522-1501-000	HF Receiver-Transmitter
522-1501-041	HF Receiver-Transmitter
522-1501-043	HF Receiver-Transmitter
522-1501-044	HF Receiver-Transmitter
522-1575-005	UHF Receiver-Transmitter
522-1660-00	HF Receiver-Transmitter
522-1660-000	HF Receiver-Transmitter
522-1660-031	HF Receiver-Transmitter
522-1660-033	HF Receiver-Transmitter
522-1660-034	HF Receiver-Transmitter
522-1836-00	Receiver
522-1867-000	Subassembly
522-2301-005	Subassembly
522-2375-00	Control, Set
522-2375-011	Control, Set
522-2375-012	Control, Set
522-2375-013	Control, Set
522-2375-014	Control, Set

PN	Description
522-2375-016	Control, Set
522-2375-017	Control, Set
522-2375-018	Control, Set
522-2375-019	Control, Set
522-2375-021	Control, Set
522-2375-022	Control, Set
522-2375-024	Control, Set
522-2375-026	Control, Set
522-2586-001	HF Receiver-Transmitter
522-2586-002	HF Receiver-Transmitter
522-2587-00	ADF
522-2587-000	UHF Receiver-Transmitter
522-2587-013	Receiver
522-2615-005	Subassembly
522-2615-006	Subassembly
522-2676-004	Mounting Base
522-2716-004	Subassembly
522-2718-005	UHF Receiver-Transmitter
522-2733-004	Subassembly
522-2753-003	Subassembly
522-2754-004	VHF Receiver-Transmitter
522-2755-004	VHF Receiver-Transmitter
522-2755-014	VHF Receiver-Transmitter
522-2756-004	VHF Receiver-Transmitter
522-2756-014	VHF Receiver-Transmitter
522-2895-00	Subassembly
522-2927-003	Subassembly
522-2927-013	Subassembly
522-2927-023	Subassembly
522-2927-024	Subassembly
522-2927-025	Subassembly
522-2927-027	Subassembly
522-2927-028	Subassembly
522-2931-004	Subassembly
522-3132-004	VHF Receiver-Transmitter
522-3165-003	Subassembly
522-3190-003	Subassembly
522-3190-014	Subassembly
522-3190-015	Subassembly
522-3190-016	Subassembly
522-3191-003	Subassembly
522-3191-004	Subassembly
522-3192-003	Subassembly
522-3193-003	Subassembly
522-3215-000	Subassembly
522-3557-003	Subassembly
522-3628-005	UHF Receiver-Transmitter
522-3742-005	UHF Receiver-Transmitter
522-3754-000	Subassembly
522-3761-001	Subassembly
522-3761-002	Subassembly
522-3830-001	Subassembly
522-3831-001	Subassembly
522-3832-001	Subassembly
522-3833-001	Subassembly
522-3834-001	Subassembly
522-3835-001	Subassembly
522-3932-001	Subassembly
522-3951-001	Subassembly
522-3951-002	Subassembly

PN	Description
522-3980-001	Subassembly
522-4075-001	UHF Receiver-Transmitter
522-4088-001	VHF Receiver-Transmitter
522-4088-003	VHF Receiver-Transmitter
522-4088-004	VHF Receiver-Transmitter
522-4088-006	VHF Receiver-Transmitter
522-4088-007	VHF Receiver-Transmitter
522-4088-009	VHF Receiver-Transmitter
522-4088-010	VHF Receiver-Transmitter
522-4088-201	VHF Receiver-Transmitter
522-4088-203	VHF Receiver-Transmitter
522-4088-204	VHF Receiver-Transmitter
522-4088-206	VHF Receiver-Transmitter
522-4088-207	VHF Receiver-Transmitter
522-4088-209	VHF Receiver-Transmitter
522-4088-210	VHF Receiver-Transmitter
522-4089-001	VHF Receiver-Transmitter
522-4089-002	VHF Receiver-Transmitter
522-4089-004	VHF Receiver-Transmitter
522-4089-005	VHF Receiver-Transmitter
522-4089-006	VHF Receiver-Transmitter
522-4089-008	VHF Receiver-Transmitter
522-4089-009	VHF Receiver-Transmitter
522-4089-010	VHF Receiver-Transmitter
522-4089-011	VHF Receiver-Transmitter
522-4089-201	VHF Receiver-Transmitter
522-4089-202	VHF Receiver-Transmitter
522-4089-204	VHF Receiver-Transmitter
522-4089-205	VHF Receiver-Transmitter
522-4089-206	VHF Receiver-Transmitter
522-4089-208	VHF Receiver-Transmitter
522-4089-209	VHF Receiver-Transmitter
522-4138-001	Subassembly
522-4190-002	Subassembly
522-4304-001	UHF Receiver-Transmitter
522-4464-001	Subassembly
522-4520-001	Subassembly
522-4611-001	Subassembly
522-4808-001	UHF Receiver-Transmitter
522-4809-001	UHF Receiver-Transmitter
522-4810-001	UHF Receiver-Transmitter
522-4811-001	UHF Receiver-Transmitter
522-4812-001	UHF Receiver-Transmitter
522-4813-001	UHF Receiver-Transmitter
522-4813-003	UHF Receiver-Transmitter
522-4828-001	HF Receiver-Transmitter
522-4828-002	HF Receiver-Transmitter
522-4829-001	HF Receiver-Transmitter
522-4829-002	HF Receiver-Transmitter
522-4830-001	HF Receiver-Transmitter
522-4830-002	HF Receiver-Transmitter
522-4844-001	Subassembly
522-4845-001	Subassembly
522-4853-001	Subassembly
522-4904-001	Subassembly
522-4951-001	UHF Receiver-Transmitter
522-5462-00	VHF Receiver-Transmitter
522-5462-000	VHF Receiver-Transmitter
528-0085-005	Amplifier
528-0086-005	Amplifier

PN	Description
528-0090-005	Receiver
528-0112-005	Subassembly
528-0113-013	Subassembly
528-0250-005	Subassembly
528-0250-025	Subassembly
528-0251-005	Subassembly
528-0329-005	Subassembly
528-0393-005	Amplifier
528-0393-025	Amplifier
528-0456-006	Subassembly
528-0500-005	Receiver
528-0500-015	Receiver
528-0500-019	Receiver
528-0501-005	Amplifier
528-0501-015	Amplifier
528-0501-018	Amplifier
528-0650-001	Subassembly
528-0671-001	Subassembly
528-0682-001	Subassembly
528-0690-001	Subassembly
528-0690-002	Subassembly
528-0690-005	Subassembly
528-0720-001	Subassembly
535180-801	UHF Power Supply
540-3489-004	Subassembly
540-3489-016	Subassembly
540-8116-004	Subassembly
540-8385-004	Power Supply
540-8945-005	Power Supply
540-8945-015	Power Supply
540-8994-005	Subassembly
540-8994-007	Subassembly
542-1370-005	Power Supply
542-1370-015	Power Supply
542-1370-025	Power Supply
542-4327-005	Subassembly
542-4327-056	Subassembly
542-4980-005	Subassembly
542-4980-056	Subassembly
542-4981-005	Receiver
542-4983-005	Amplifier
542-4990-006	Subassembly
542-4992-005	Amplifier
542-4992-045	Amplifier
542-4993-003	Amplifier
542-4994-005	Amplifier
542-4994-046	Amplifier
543-3338-005	Amplifier
543-3338-046	Amplifier
543-3339-006	Receiver
543-3339-057	Receiver
543-6301-005	Receiver
543-6301-025	Receiver
543-6303-005	Amplifier
543-6304-004	Power Supply
544-0293-005	Power Supply
544-0293-015	Power Supply
544-0300-005	Subassembly
544-0300-015	Subassembly
544-5468-003	Amplifier

PN	Description
544-5543-005	Receiver
544-9283-000	Amplifier
544-9285-005	Subassembly
544-9286-000	Subassembly
544-9289-005	Subassembly
544-9290-005	Amplifier
544-9291-000	Power Supply
544-9292-000	Power Supply
54500396	Tacan
545-4971-000	Power Supply
545-5858-000	Power Supply
546-2142-005	Subassembly
546-6053-000	Amplifier
551A	
5826-920-7107	Control, Set
5826-920-7108	Mounting Base
5826-985-9169	Nav Receiver
5826-985-9171	Subassembly
601-4176-001	Subassembly
608-9020-002	UHF Amplifier
608-9020-003	UHF Amplifier
608-9025-002	UHF
608-9026-001	UHF Amplifier
608-9419-002	Subassembly
608-9419-003	Subassembly
608-9420-002	Subassembly
608-9420-003	Subassembly
617-8408-001	Power Supply
617-8409-001	Receiver
617-8410-001	Subassembly
617-8411-001	Subassembly
617-9101-003	Subassembly
617-9104-003	Subassembly
617-9107-003	Subassembly
617-9110-004	Subassembly
617-9113-004	Subassembly
617-9113-006	Subassembly
617-9117-004	Subassembly
617-9120-003	Subassembly
617-9123-003	Subassembly
617-9126-004	Subassembly
617-9129-003	Subassembly
617-9129-004	Subassembly
617-9132-004	Subassembly
617-9135-003	Subassembly
617-9148-002	Subassembly
617-9617-001	UHF Amplifier
617-9617-002	UHF Amplifier
617-9618-001	Subassembly
617-9621-001	UHF
617-9621-002	UHF Receiver-Transmitter
617-9621-004	Subassembly
617-9621-006	UHF
618-7241-001	UHF Control, Set
618-7241-004	UHF Control, Set
618-7362-001	UHF Control, Set
618-9020-003	UHF Amplifier
618M-1	VHF Receiver-Transmitter
618M-1A	VHF Receiver-Transmitter
618M-1B	VHF Receiver-Transmitter

PN	Description
618M-1C	VHF Receiver-Transmitter
618M-1D	VHF Receiver-Transmitter
618M-3A	VHF Receiver-Transmitter
618T-1	HF Receiver-Transmitter
618T-1B	HF Receiver-Transmitter
618T-2	HF Receiver-Transmitter
618T-2B	HF Receiver-Transmitter
618T-3	HF Receiver-Transmitter
618T-3B	HF Receiver-Transmitter
618T-4	HF Receiver-Transmitter
618T-4B	HF Receiver-Transmitter
618T-5	HF Receiver-Transmitter
618T-5B	HF Receiver-Transmitter
618T-6	HF Receiver-Transmitter
618T-6B	HF Receiver-Transmitter
621-7881-002	UHF Receiver-Transmitter
622-0356-001	Receiver-Transmitter
622-0356-002	Receiver-Transmitter
622-0356-003	UHF Receiver-Transmitter
622-0478-002	Tacan
622-0507-001	Tacan
622-0507-002	Tacan
622-0507-003	Tacan
622-0507-004	Tacan
622-0507-005	Tacan
622-0507-006	Tacan
622-0748-001	Control, Set
622-0748-002	Control, Set
622-0876-001	Receiver
622-0876-002	Receiver-Transmitter
622-1270-001	Transponder
622-1334-002	VHF Receiver-Transmitter
622-1365-001	
622-1391-003	Subassembly
622-1391-004	UHF Control, Set
622-1394-002	Subassembly
622-1396-101	VHF Receiver-Transmitter
622-1396-102	VHF Receiver-Transmitter
622-1396-103	VHF Receiver-Transmitter
622-1396-110	VHF Receiver-Transmitter
622-1396-111	VHF Receiver-Transmitter
622-1396-203	VHF Receiver-Transmitter
622-1396-205	VHF Receiver-Transmitter
622-1396-206	VHF Receiver-Transmitter
622-1396-208	VHF Receiver-Transmitter
622-1396-209	VHF Receiver-Transmitter
622-1396-210	VHF Receiver-Transmitter
622-1524-001	UHF Receiver-Transmitter
622-1524-010	UHF Receiver-Transmitter
622-1524-017	UHF Receiver-Transmitter
622-1524-018	UHF Receiver-Transmitter
622-1524-021	UHF Receiver-Transmitter
622-1524-022	UHF Receiver-Transmitter
622-1524-XXX	UHF Receiver-Transmitter
622-1627-001	Receiver-Transmitter
622-1627-002	Receiver-Transmitter
622-1627-003	Receiver-Transmitter
622-1627-004	Receiver-Transmitter
622-1627-005	Receiver-Transmitter
622-1627-006	Receiver-Transmitter

PN	Description
622-1628-001	UHF Receiver-Transmitter
622-1628-002	UHF Receiver-Transmitter
622-1629-001	Control, Set
622-1678-001	Tacan
622-1678-002	Converter
622-1678-004	Converter
622-2287-001	UHF Control, Set
622-2287-002	UHF Control, Set
622-2287-003	UHF Control, Set
622-2287-004	UHF Control, Set
622-2360-002	Control, Set
622-2510-001	Tacan
622-2510-002	Control, Set
622-2510-003	Receiver-Transmitter
622-2510-004	Control, Set
622-2511-001	Control, Set
622-2511-002	Control, Set
622-2586-002	HF Receiver-Transmitter
622-2587-001	HF Receiver-Transmitter
622-2588-001	HF Receiver-Transmitter
622-2588-002	HF Receiver-Transmitter
622-2589-001	HF Receiver-Transmitter
622-2590-001	HF Receiver-Transmitter
622-2590-002	HF Receiver-Transmitter
622-2591-001	HF Receiver-Transmitter
622-3385-001	HF Receiver
622-3385-002	HF Receiver
622-3385-003	HF Receiver
622-3385-004	HF Receiver
622-3385-005	HF Receiver
622-3385-006	HF Receiver
622-3385-007	HF Receiver
622-3385-008	HF Receiver
622-3393-001	HF Receiver
622-3393-002	HF Receiver
622-3393-003	HF Receiver
622-3393-004	HF Receiver
622-3393-005	HF Receiver
622-3393-006	HF Receiver
622-3393-007	HF Receiver
622-3393-008	HF Receiver
622-3393-009	HF Receiver
622-3393-010	HF Receiver
622-4037-001	VHF Receiver-Transmitter
622-4037-002	VHF Receiver-Transmitter
622-4037-003	VHF Receiver-Transmitter
622-4037-004	VHF Receiver-Transmitter
622-4037-005	VHF Receiver-Transmitter
622-4037-006	VHF Receiver-Transmitter
622-4038-001	VHF Receiver-Transmitter
622-4038-002	VHF Receiver-Transmitter
622-4039-001	VHF Control, Set
622-4039-002	VHF Control, Set
622-4039-003	VHF Control, Set
622-4039-004	VHF Control, Set
622-4039-005	VHF Control, Set
622-4039-006	VHF Control, Set
622-4039-007	VHF Control, Set
622-4039-008	VHF Control, Set
622-4039-009	VHF Control, Set

PN	Description
622-4039-010	VHF Control, Set
622-4039-011	VHF Control, Set
622-4039-012	VHF Control, Set
622-4039-013	VHF Control, Set
622-4039-014	VHF Control, Set
622-4039-015	VHF Control, Set
622-4039-016	VHF Control, Set
622-4039-017	VHF Control, Set
622-4039-018	VHF Control, Set
622-4287-001	VHF Mounting Base
622-4288-001	VHF Mounting Base
622-4289-001	VHF Mounting Base
622-4290-001	VHF Mounting Base
622-4291-001	VHF Subassembly
622-4595-001	VHF Receiver-Transmitter
622-4957-001	CONTROL RADIO
622-4957-003	CONTROL RADIO
622-4957-004	CONTROL RADIO
622-5528-001	Receiver-Transmitter
622-6137-001	Receiver
622-6152-001	VHF Receiver-Transmitter
622-6321-001	Receiver-Transmitter
622-6323-001	
622-6324-002	
622-6521-013	Control, Set
622-9076-001	Control, Set
623-2080-001	HF Subassembly
623-2080-002	HF Subassembly
623-2080-003	HF Subassembly
623-2080-004	HF Subassembly
623-2085-001	HF Subassembly
628-6067-002	HF Subassembly
634-2647-001	HF Subassembly
635-0656-001	HF Subassembly
635-0657-001	HF Subassembly
635-0696-001	HF Subassembly
635-0742-001	HF Subassembly
635-0748-001	HF Subassembly
635-0749-001	HF Subassembly
635-0751-002	HF Subassembly
635-0752-002	HF Subassembly
635-0759-002	HF Subassembly
635-0759-004	HF Subassembly
635-0772-001	HF Subassembly
635-0772-004	HF Subassembly
635-0825-004	HF Subassembly
635-0825-010	HF Subassembly
635-0825-011	HF Subassembly
635-0830-001	HF Subassembly
635-0830-002	HF Subassembly
635-0900-001	HF Subassembly
635-4930-001	HF Subassembly
635-4930-002	HF Subassembly
635-8660-001	UHF Control, Set
635-8660-002	UHF Control, Set
635-9629-001	HF Subassembly
635-9629-002	HF Subassembly
635-9629-003	HF Subassembly
635-9629-004	HF Subassembly
635-9629-005	HF Subassembly

PN	Description
635-9629-006	HF Subassembly
635-9629-007	HF Subassembly
635-9649-001	HF Subassembly
635-9697-001	HF Subassembly
637-1530-001	HF Subassembly
637-1530-002	HF Subassembly
637-1530-004	HF Subassembly
637-1767-001	HF Subassembly
637-1781-007	HF Subassembly
637-2647-002	HF Subassembly
637-2647-005	HF Subassembly
637-2650-001	HF Subassembly
637-2650-002	HF Subassembly
637-2650-006	HF Subassembly
637-6453-001	UHF Subassembly
637-6460-001	VHF Power Supply
637-6978-001	Power Supply
638-6437-001	HF Subassembly
638-6896-001	HF Subassembly
63901-009-1	UHF Receiver-Transmitter
642-3135-001	HF Subassembly
642-3137-001	HF Subassembly
642-3224-001	HF Subassembly
642-3224-002	HF Subassembly
646-5672-002	HF Subassembly
653278	Amplifier
671U-4A	
705906-801	UHF Receiver-Transmitter
705906-802	UHF Receiver-Transmitter
705906-803	UHF Receiver-Transmitter
705906-804	UHF Receiver-Transmitter
705906-805	UHF Receiver-Transmitter
705906-XXX	UHF Receiver-Transmitter
705907-801	UHF Receiver-Transmitter
705908-801	UHF Control, Set
705908-802	UHF Control, Set
705908-803	UHF Control, Set
705908-804	UHF Control, Set
705908-805	UHF Control, Set
705908-XXX	UHF Control, Set
706075-801	UHF Control, Set
706075-802	UHF Control, Set
706075-803	UHF Control, Set
706075-804	UHF Control, Set
706075-805	UHF Control, Set
706075-XXX	UHF Control, Set
706076-801	UHF Control, Set
706076-802	UHF Control, Set
706076-803	UHF Control, Set
706076-804	UHF Control, Set
706076-805	UHF Control, Set
706076-XXX	UHF Control, Set
706077-XXX	UHF Receiver-Transmitter
706079-801	UHF Control, Set
706079-802	UHF Control, Set
706079-803	UHF Control, Set
706079-804	UHF Control, Set
706079-805	UHF Control, Set
706961-801	CONTROL
706961-802	CONTROL

PN	Description
706961-803	CONTROL
706961-804	CONTROL
706961-805	CONTROL
706962-801	CONTROL
706962-802	CONTROL
706962-803	CONTROL
706962-804	CONTROL
706962-805	CONTROL
706963-801	CONTROL
706963-802	CONTROL
706963-803	CONTROL
706963-804	CONTROL
706963-805	CONTROL
706976-801	TRANSCEIVER
706976-802	TRANSCEIVER
706976-803	TRANSCEIVER
706976-804	TRANSCEIVER
706976-805	TRANSCEIVER
706977-801	TRANSCEIVER
706978-801	CONTROL
706978-802	CONTROL
706978-803	CONTROL
706978-804	CONTROL
706978-805	CONTROL
707060-801	TRANSCEIVER
707061-801	TRANSCEIVER
707061-802	TRANSCEIVER
707061-803	TRANSCEIVER
707061-804	TRANSCEIVER
707061-805	TRANSCEIVER
707061-XXX	UHF Receiver-Transmitter
707073	UHF Receiver-Transmitter
707073-801	UHF Receiver-Transmitter
707074-XXX	UHF Receiver-Transmitter
707224-801	TRANSCEIVER
707224-XXX	UHF Receiver-Transmitter
707648-801	TRANSCEIVER
707648-802	TRANSCEIVER
707648-803	TRANSCEIVER
707648-804	TRANSCEIVER
707648-805	TRANSCEIVER
707648-XXX	UHF Receiver-Transmitter
707650-801	UHF Receiver-Transmitter
707656-801	TRANSCEIVER
70A3810206-480	Subassembly
722-5009-001	Subassembly
722-5234-001	Subassembly
757-0957-001	Subassembly
757-0957-003	Subassembly
757-1013-001	Subassembly
787-6778-001	UHF Receiver-Transmitter
787-6934-007	HF RECEIVER/EXCITER
787-6934-011	HF RECEIVER/EXCITER
792-6293-001	Receiver
8039051096	Subassembly
8070000058	Receiver-Transmitter
8070000091	Receiver-Transmitter
8070047097	Receiver-Transmitter
8070060093	Control, Set
8070070099	Control, Set

PN	Description
8070100052	Control, Set
8070100095	Control, Set
807B	VHF COMM
899L1	Converter
913G-1	Control, Set
913G-2	Control, Set
913G-4	Control, Set
918844-801	UHF
918845-801	UHF
918846-801	UHF
919403-801	UHF Receiver
A2	Amplifier
AAU32A	Indicator
AMP	Amplifier
AN/ARC109	VHF Receiver-Transmitter
AN/ARC-114	VHF Receiver-Transmitter
AN/ARC-114A	VHF Receiver-Transmitter
AN/ARC-115	VHF Receiver-Transmitter
AN/ARC-115A	VHF Receiver-Transmitter
AN/ARC-115A(V)1	VHF Receiver-Transmitter
AN/ARC159	UHF Receiver-Transmitter
AN/ARC-159	UHF Receiver-Transmitter
AN/ARC159(V)1	UHF Receiver-Transmitter
AN/ARC51	UHF Receiver-Transmitter
AN/ARC51A	UHF Receiver-Transmitter
AN/ARC54	VHF Receiver-Transmitter
AN/ARN-123	Nav Receiver
AN/ARN-123(V)1	Receiver
AN/ARN-123(V)4	Nav Receiver
AN/PRC-90	Receiver-Transmitter
AN/PRC90-1	Receiver-Transmitter
AN/PRC90-2	Receiver-Transmitter
APX-100	Transponder
APX-72	Transponder
ARC 159	UHF Receiver-Transmitter
ARC-109	UHF Receiver-Transmitter
ARC114	UHF Receiver-Transmitter
ARC114A	VHF Receiver-Transmitter
ARC115	VHF Receiver-Transmitter
ARC115A	UHF Receiver-Transmitter
ARC115A(V)1	UHF Receiver-Transmitter
ARC159(V)1	UHF Receiver-Transmitter
ARC-159(V)2	UHF Receiver-Transmitter
ARC-159(V)3	UHF Receiver-Transmitter
ARC-159(V)4	UHF Receiver-Transmitter
ARC-159(V)5	UHF Receiver-Transmitter
ARC-159A(V)5	UHF Receiver-Transmitter
ARC-159A(V)8	UHF Receiver-Transmitter
ARC-164	UHF Receiver-Transmitter
ARC-51	UHF Receiver-Transmitter
ARC51A	UHF Receiver-Transmitter
ARC-52	UHF Receiver-Transmitter
ARC54	VHF Receiver-Transmitter
ARN-118	Tacan
ARN-123	Receiver
ARN-52	Tacan
ARN-82	Receiver
ARN-89	Control, Set
C-10048/ARN-123	Control, Set
C-10048/ARN-123(V)	Control, Set

PN	Description
C10056/A	Control, Set
C10057/A	Control, Set
C10058/A	Control, Set
C-10058/A	Control, Set
C10059/A	Control, Set
C10059A/1	Control, Set
C10060/A	Control, Set
C10061/A	Control, Set
C10062/A	Control, Set
C-10604	VHF Control, Set
C-10604(V)1	VHF Control, Set
C-10604(V)2	VHF Control, Set
C-10604(V)3	VHF Control, Set
C-10604(V)4	VHF Control, Set
C-10604(V)5	VHF Control, Set
C-10604(V)6	VHF Control, Set
C-10605(V)1	VHF Control, Set
C-10605(V)2	VHF Control, Set
C-10605(V)3	VHF Control, Set
C-10605(V)4	VHF Control, Set
C-10605(V)5	VHF Control, Set
C-10605(V)6	VHF Control, Set
C-10606(V)1	VHF Control, Set
C-10606(V)2	VHF Control, Set
C-10606(V)3	VHF Control, Set
C-10606(V)4	VHF Control, Set
C-10606(V)5	VHF Control, Set
C-10606(V)6	VHF Control, Set
C10782/A	Control, Set
C-2275/ARN	Control, Set
C6280/APX	Transponder
C-6280A/APX	Transponder
C-6533/ARC	Control, Set
C-6873A/ARN-82	Control, Set
C-6873B/ARN-82	Control, Set
C-7088/ARC-131	VHF Control, Set
C-7197/ARC-134	VHF Control, Set
C-7392/ARN-89	Control, Set
C-7392A/ARN-89	Receiver-Transmitter
C7999/GRC-171(V)	Control, Set
C-9533/ARC-164	UHF Control, Set
C-9533/ARC-164(V)	UHF Control, Set
C-9533A	CONTROL
C-9533A/ARC-164	CONTROL
C-9533A/ARC-164(V)	CONTROL BOX
C9603/A	Control, Set
C-962S	Control, Set
C-9680/ARC-164	UHF Control, Set
C-9680/ARC-164(V)	UHF Control, Set
C-9680A/ARC-164	CONTROL
C-9680A/ARC-164(V)	CONTROL BOX
C-9681/164(V)	
C-9681/ARC-164	UHF Control, Set
C-9681/ARC-164(V)	UHF Control, Set
C-9681A/ARC-164	CONTROL BOX
C-9681A/ARC-164(V)	CONTROL BOX
C-9682/ARC-164(V)	CONTROL BOX
C-9682A/ARC-164	CONTROL
C-9682A/ARC-164(V)	CONTROL BOX
C-9815	UHF Control, Set

PN	Description
C-9815/ARC159	UHF Control, Set
C9815/ARC159(V)	UHF Control, Set
C-9816	UHF Control, Set
C-9816/ARC159	UHF Control, Set
C9816/ARC159(V)	UHF Control, Set
C-9817	UHF Control, Set
C9817/ARC159	UHF Control, Set
C9817/ARC159(V)	UHF Control, Set
C-9818	UHF Control, Set
C9818/ARC159	UHF Control, Set
C9818/ARC159(V)	UHF Control, Set
CM-4821	VHF Subassembly
CN-1314/A	Gyro
CN-261A	Control, Set
CN-268A	Control, Set
CN-269A	Control, Set
CN-998B/ASN-43	Gyro
DY-150/ARN	Subassembly
GB4422	UHF Receiver-Transmitter
GB4423	UHF Receiver-Transmitter
GB4834	UHF Receiver-Transmitter
GB4948	UHF Receiver-Transmitter
GB4951	UHF Receiver-Transmitter
GB4953	UHF Receiver-Transmitter
GB5116	UHF Receiver-Transmitter
GE5109	Subassembly
GE5115	UHF Receiver-Transmitter
GE5116	UHF Receiver-Transmitter
GE5118	UHF Receiver-Transmitter
GRC 211	VHF Receiver-Transmitter
GRC-171	Receiver-Transmitter
GRC-211	Receiver-Transmitter
GSB-900 DX	Receiver-Transmitter
GSB-900 SC	Receiver-Transmitter
GSB-900 SC/R	Receiver-Transmitter
ID-1347/ARN-82	Subassembly
ID-1347A/ARN-82	Subassembly
ID-1347B/ARN-2	Subassembly
ID-1347C/ARN-2	Subassembly
ID-637/ARN	Indicator
KA-39	Power Supply
KMA-24H	Intercom
KN-62A	DME
KN-65A	DME
KN-72	Converter
KN-75	Converter
KT-76A	Transponder
KX-155	VHF Receiver-Transmitter
KX-165	VHF Receiver-Transmitter
KX-170B	VHF Receiver-Transmitter
MS15795-802	Subassembly
MS165-67	Subassembly
MS353338-134	Subassembly
MS51957-2	Subassembly
MS51957-3	Subassembly
MS51957-5	Subassembly
MT-263B	Mounting Base
MT-265A	Mounting Base
MT-3664/ARC-131	VHF Mounting Base
MT-4834/ARN-123	Mounting Base

PN	Description
MT-4834/ARN-123(V)	Mounting Base
MT-4834/ARN-123(V)3	Mounting Base
MT-6048	VHF Mounting Base
MT-6049	VHF Mounting Base
MT-6050	VHF Mounting Base
MT-6051	VHF Mounting Base
MX11499	Converter
MX11499/ARN118(V)	Converter
MX9577/A	Converter
MX-9577/A	Tacan
PP-7117/ARC-164(V)	POWER SUPPLY
PP-7541	VHF Power Supply
PRT-551A	PORTABLE T/R
PRT-661A	PORTABLE T/R
R-1388/ARN-82	Nav Receiver
R-1388A/ARN-82	Receiver
R-1496	Receiver
R-1496A	Receiver
R-2023/ARN-123	Receiver
R-2023/ARN-123(V)	Receiver
R-2139/ARN-123	Receiver
R-2139/ARN-123(V)	Nav Receiver
R-836/ARN	Nav Receiver
RN-260B	
RN-262B	Receiver
RT-1063B/APX-101	TRANSPONDER
RT-1063C/APX-101	TRANSPONDER
RT-1145/-164(V)	TRANSCEIVER
RT-1145/ARC-164	UHF Receiver-Transmitter
RT-1145A/ARC-164	TRANSCEIVER
RT-1145A/ARC-164(V)	TRANSCEIVER
RT1145B/ARC164	UHF Receiver-Transmitter
RT-1145C/ARC-164	TRANSCEIVER
RT-1145C/ARC-164(V)	TRANSCEIVER
RT-1156/APX-100	TRANSPONDER
RT-1156/APX-100(V)	TRANSPONDER
RT-1159/A	Tacan
RT-1167/ARC-164	UHF Receiver-Transmitter
RT-1167B/ARC-164	TRANSCEIVER
RT-1167C/ARC-164	UHF Receiver-Transmitter
RT-1168/ARC-164	UHF Receiver-Transmitter
RT-1168/ARC-164(V)	TRANSCEIVER
RT-1168A/ARC-164	TRANSCEIVER
RT-1168A/ARC-164(V)	TRANSCEIVER
RT-1168B/ARC-164	UHF Receiver-Transmitter
RT-1168C/ARC-164	UHF Receiver-Transmitter
RT-1168C/ARC-164(V)	TRANSCEIVER
RT-1250A/ARC164	Receiver-Transmitter
RT-1284/APX-100	TRANSPONDER
RT-1284/APX-100(V)	TRANSPONDER
RT-1284A/APX-100	Transponder
RT-1284A/APX-100(V)	
RT-1284B/APX-100(V)	TRANSPONDER
RT-1285/APX-100	TRANSPONDER
RT-1285/APX-100(V)	TRANSPONDER
RT-1285A/APX-100	Transponder
RT-1285A/APX-100(V)	TRANSPONDER
RT-1285B/APX-100(V)	TRANSPONDER
RT-1286/APX-100	TRANSPONDER
RT-1286/APX-100(V)	TRANSPONDER

PN	Description
RT-1286A/APX-100	Transponder
RT-1286A/APX-100(V)	TRANSPONDER
RT-1286B/APX-100(V)	TRANSPONDER
RT-1296/APX-100	TRANSPONDER
RT-1296/APX-100(V)	TRANSPONDER
RT-1296A/APX-100	Transponder
RT-1296A/APX-100(V)	TRANSPONDER
RT-1296B/APX-100(V)	TRANSPONDER
RT-1299(V)1/ARC-186(V)	VHF Receiver-Transmitter
RT-1299(V)2/ARC-186(V)	VHF Receiver-Transmitter
RT-1299(V)3/ARC-186(V)	VHF Receiver-Transmitter
RT-1299(V)4/ARC-186(V)	VHF Receiver-Transmitter
RT-1299(V)5/ARC-186(V)	VHF Receiver-Transmitter
RT-1299(V)6/ARC-164(V)	VHF Receiver-Transmitter
RT-1300/ARC-186(V)	VHF Receiver-Transmitter
RT-1300A/ARC-186(V)	VHF Receiver-Transmitter
RT-1504/ARC-164	TRANSCEIVER
RT-1504/ARC-164(V)	TRANSCEIVER
RT-1505/ARC-164	UHF Receiver-Transmitter
RT-1505/ARC-164(V)	TRANSCEIVER
RT-1518/ARC-164(V)	VHF Receiver-Transmitter
RT-1557/APX-100	TRANSPONDER
RT-1558/APX-100	TRANSPONDER
RT-1558/APX-100(V)	TRANSPONDER
RT-1558A/APX-100(V)	TRANSPONDER
RT-186	VHF Receiver-Transmitter
RT-332/ARC-52	UHF Receiver-Transmitter
RT348/ARC54	RECEIVER TRANSMITTER
RT-384/ARN-52	Tacan
RT-384A/ARN-52	Tacan
RT-384B/ARN-52	Tacan
RT551A	TRANSCEIVER
RT-551A	TRANSCEIVER
RT-650/ARC-51	UHF Receiver-Transmitter
RT661	TRANSCEIVER
RT661A	TRANSCEIVER
RT742/ARC51BX	UHF Receiver-Transmitter
RT742B/ARC51BX	UHF Receiver-Transmitter
RT742C/ARC51BX	UHF Receiver-Transmitter
RT-743/ARC-51A	UHF Receiver-Transmitter
RT-743A/ARC-51A	UHF Receiver-Transmitter
RT-743B/ARC-51A	UHF Receiver-Transmitter
RT-749/ARC-109	UHF Receiver-Transmitter
RT749/ARC109(V)	UHF Receiver-Transmitter
RT-767/ARC-51B	UHF Receiver-Transmitter
RT-767A/ARC-51B	UHF Receiver-Transmitter
RT-767B/ARC-51B	UHF Receiver-Transmitter
RT-780/ARC-51AX	UHF Receiver-Transmitter
RT-780A/ARC-51AX	UHF Receiver-Transmitter
RT-780B/ARC-51AX	UHF Receiver-Transmitter
RT-823/ARC-131	VHF Receiver-Transmitter
RT-857/ARC-134	VHF Receiver-Transmitter
RT-859/APX-72	Transponder
RT-859A/APX-72	Transponder
RT-9600	UHF Receiver-Transmitter
RT-9600F	Radio Telephone
RT-9600F-77	UHF Receiver-Transmitter
RT980/GRC-171(V)	UHF Receiver-Transmitter
SCDL595575	VHF Receiver-Transmitter
SMA617928-4	Subassembly

PN	Description
SMB595940-1	Subassembly
SM-B-596103	Subassembly
SM-B-596125	Subassembly
SMB596133	Subassembly
SM-B-596347	Subassembly
SMB605951	Subassembly
SMB617077	Subassembly
SMB617939-1	Subassembly
SM-B-617960	Subassembly
SM-B-617963	Subassembly
SMB617966	Subassembly
SM-B-618110	Subassembly
SM-B-618113	Subassembly
SM-B-618141	Subassembly
SM-B-618158	Subassembly
SM-B-618206	Subassembly
SMB618251	Subassembly
SMB618278	Subassembly
SMB618852	Subassembly
SM-B-618872	Subassembly
SM-B-618875	Subassembly
SM-B-632225	Subassembly
SMB632254	Subassembly
SMB632256	Subassembly
SMB632263	Subassembly
SMB632280	Subassembly
SM-B-632312	Subassembly
SM-B-632330	Subassembly
SMB692565	Subassembly
SMB692580	VHF Receiver-Transmitter
SM-B-692580	Receiver-Transmitter
SMB692590	UHF Receiver-Transmitter
SM-B-692590	VHF Receiver-Transmitter
SM-B-692656	Subassembly
SM-B-692708	Subassembly
SMB692746	Subassembly
SMB692851	Subassembly
SM-B-692882	Subassembly
SM-B-693079	Subassembly
SM-B-693081	Subassembly
SMB693086	Subassembly
SMB693091	Subassembly
SMB726670	VHF Receiver-Transmitter
SMB726718	Subassembly
SMB726723	Subassembly
SMB726729	Subassembly
SMB726753	Subassembly
SMB882573	VHF Receiver-Transmitter
SM-B-882753	Receiver-Transmitter
SMC596013-9	Subassembly
SMC596378-20	Subassembly
SMC617825	Subassembly
SMC617837-11	Subassembly
SMC617843	Subassembly
SMC632177	Subassembly
SM-D-632010	Subassembly
TDR-90	Transponder
UHF-719A	UHF Receiver-Transmitter
VHF-20	VHF Receiver-Transmitter
VHF-22A	VHF Receiver-Transmitter

PN**Description**

VHF-400

Receiver-Transmitter

VIR-30

Receiver

VIR-32

Receiver